

## Honeywell 1400g Enter Suffix

Scan all barcodes from top to bottom



## Activate Custom Defaults



## Clear All Suffixes



## Add CR Suffix All Symbolologies