



SYMBOL LS2208 BARCODE SCANNER

BARCODE SCANNER SETUP

SCAN FIRST

Set defaults



SCAN SECOND

[CR] Suffix



SCAN THIRD

General settings

